

# Folk- and Bluegrass-Friendly Chord Bars for OS21\*

\*And all 21-chord Oscar Schmidts except for the OS73C

Chord bars are 10 1/8 inches long. Check to make certain your chart has printed at exactly 100%.

Fold the printed chart and hold it against the strings on your autoharp to verify the accuracy.

If necessary, adjust the scaling on your print screen to get the correct string spacing.

Mark your chord bars according to this chart.

Hold your marked chord bars over the strings to make certain they align properly.

If you are cutting "blank" chord bars, notch a V where each string needs to be "open."

Do not try to make the cuts square.

