


# Reconfiguring Standard 21-Chord Autoharp for Folk, Bluegrass, and Country (Variation 1)

Involves refelting the Ab, and Bb7 chord bars to add Bm, and F#m


Top row remains the same (for now)



Middle row remains the same (for now).




Reconfigure Ab and Bb7 to Bm and F#m; move to right end.  
Move remaining chord bars to the left two spaces.



## Alternatively, replace the Cm as well.

This moves the relative minors as close as possible to their major chords. It also lets you play complex songs in A.



**Do NOT disassemble your autoharp over shag carpet!**